
Model Name: DORNBIRN X
Model No: KF.16DX.1214


VOGTINDUSTRIES.COM


Before you begin:

- Please take note of different standards and regulations that are dictated by your local plumbing codes. This product is certified in accordance with North American building codes.
- We insist that you use services of a professional plumber with experience in the installation of similar fixtures.
- Ensure that the piping system is well secured to prevent rattling, vibration and banging noises caused by a water hammer. We also recommend that you use water hammer arrestors.
- Remove the cartridge, Purge the water supply system for around 30 seconds, and then carefully reinstall the cartridge.

Tools and equipment you will need:


A 

B 

C 
(9/16-24UNEF)

D 


Waterway diagram:





vogt


PURE QUALITY. PURE DESIGN.


Parts/Assembly
Model Name: DORNBIRN X
Model No: KF.16DX.1214






1
Hot
Caliente
Chaud
Cold
Frio
Froid



2
A
B
D
E
F



3
A



4
Hot
(Red)
9/16-24UNEF
Cold
(Blue)
Hot
Caliente
Chaud
Cold
Frio
Froid



5
Open
Open



6
I
J



7
J
I
H


8
H


9
H
C


10
G
51mm (2")
76mm (3")


11


12