


Model Name: KAPFENBERG ROMAN  
TUB FILLER  
Model No: BF.KG.2000.XX

**vogt**  
VOGTINDUSTRIES.COM


### Before you begin:

- Please take note of different standards and regulations that are dictated by your local plumbing codes. This product is certified in accordance with North American building codes.
- We insist that you use services of a professional plumber with experience in the installation of similar fixtures.
- Ensure that the piping system is well secured to prevent rattling, vibration and banging noises caused by a water hammer. We also recommend that you use water hammer arrestors.
- Remove the cartridge, Purge the water supply system for around 30 seconds, and then carefully reinstall the cartridge.

### Tools and equipment you will need:



### Waterway diagram:



**vogt**

PURE QUALITY AND DESIGN

Parts/Assembly

Model Name: KAPFENBERG

ROMAN TUB FILLER

Model No: BF.KG.2000.XX

